

RG-WALL 1600-N



RG-WALL 1600-N



1.


2.

HA

web	192.168.1.2	80	202.1.1.11	8000
smtp	192.168.1.3	25	202.1.1.11	25

- 1
- 2
- 3
- 4
- 5

DNAT



NAT IP

IP / IP

IP

SNAT

DNAT


NAT

IP

IP

NAT



NAT






Three overlapping '添加' (Add) dialog boxes are shown, illustrating the process of adding hosts to a NAT configuration.

- Left Dialog:** Name: 202.1.1.10. Host IP list contains 202.1.1.10 with a red 'x' icon. Sharing options: 共享, 允许, 禁止, .
- Middle Dialog:** Name: 192.168.1.2. Host IP list contains 192.168.1.2 with a red 'x' icon. Sharing options: 共享, 允许, 禁止, .
- Right Dialog:** Name: 192.168.1.3. Host IP list contains 192.168.1.3 with a red 'x' icon. Sharing options: 共享, 允许, 禁止, . Buttons: .





NAT

NAT

添加

基本信息 高级信息 安全引擎

克隆模板

* 名称 fw706205907

描述

源

源地址 any

源区域

源端口

用户

目的

目的地址 192.168.1.2

目的区域

HTTP

添加

基本信息 高级信息 安全引擎

DNAT	webserver	8000
DNAT	IP	80
HTTP	80	





1.

2.

HA


HA


HA

HA

;

,CPU









```
      "      "      eth0
eth0      IP      192.168.1.201
eth2      eth2      IP
10.1.1.2
eth1      "      "
```

HA




HA




HA



HA





THANKS

29

100036

Office Tel: 010-51715999

Fax: 010-51413399

A 11

